




# Symbole

(D)



## Baugruppe

- Vorderachse
- Hinterachse

## Einbauort

- oben
- unten
- beidseitig
- links
- rechts
- mitte
- vorne
- hinten
- innen
- außen
- getriebeseitig

## Produkthinweise

- Auslaufartikel
- wahlweise
- (x1) Anzahl pro Achse: 1
- (x2) Anzahl pro Achse: 2
- (x4) Anzahl pro Achse: 4

## Fahrzeughinweise


- LHD für Linkslenker
- RHD für Rechtslenker
- M Schaltgetriebe
- A Automatikgetriebe
- für Fahrzeuge mit Servolenkung
- für Fahrzeuge ohne Servolenkung
- für Fahrzeuge mit Klimaanlage
- für Fahrzeuge ohne Klimaanlage
- Niveauregulierung
- OHD verstärkte Radaufhängung

## Spalte „i“

- 02.2004-> ab Baujahr
- >02.2004 bis Baujahr
- Chass. ...-> ab Fahrgestellnummer
- >Chass. ... bis Fahrgestellnummer
- Mot. ...-> ab Motornummer
- >Mot. ... bis Motornummer
- Orga Nr. ... -> ab Organisationsnummer
- >Orga Nr. ... bis Organisationsnummer
- Mot. Motorcode



# Symbols



## Assembly

- front axle
- rear axle

## Location

- upper
- lower
- on both sides
- left
- right
- middle
- front
- back
- inside
- outside
- transmission side

## Product information

- discontinued items
- according to choice
- (x1) number per axle: 1
- (x2) number per axle: 2
- (x4) number per axle: 4

## Vehicle information

- LHD for left-hand drive vehicles
- RHD for right-hand drive vehicles
- M manual transmission
- A automatic transmission
- for vehicles with power steering
- for vehicles without power steering
- for vehicles with air conditioning
- for vehicles without air conditioning
- level control
- OHD reinforced wheel suspension

## Column "i"

- 02.2004-> from model year
- >02.2004 to model year
- Chass. ...-> from chassis number
- >Chass. ... to chassis number
- Mot. ...-> from engine number
- >Mot. ... to engine number
- Orga Nr. ... -> from control number
- >Orga Nr. ... to control number
- Mot. engine code